Freezeless Residential Wall Faucets Accessories Sold Separately



Freezeless Residential Wall Faucets Information

WF-MS Mounting Sleeve U.S. Patent 8,151,821 B2

FOR USE WITH MODELS 14, 16, 17 & 19 ONLY

The WF-MS Wall Faucet Mounting Sleeve takes the guesswork out of how far to stub-out Woodford freezeless faucets through brick, stone or stucco veneers. Built-in anchors provides a secure installation for the faucet

The Mounting Sleeve allows the plumber to determine a stub-in location and set an adjustable finish depth required by the brick or stone mason. A numbered scale is built into the top of the Mounting Sleeve


The faucet installation is completed by mating the faucet wall flange to the front of the Mounting Sleeve and securing with two, furnished flange screws. The proper drain angle is automatically set by the rear Tube Rest.

SL-17 Stem Lock

FITS WOODFORD MODELS: 14, 16, 17, 19, 22, V22

- Vandal Resistant
- · Easy to retrofit
- Replace the standard packing nut with furnished solid brass locking nut and snap on the Lock. 2 keys are included.
- Easy access and operation:
- 1. Unlock and remove the Lock to reveal the faucet operating rod
- 2. Use Tee Key to operate faucet.





DMP Drywall Mounting Plate

FOR USE WITH MODELS 22 AND V22 ONLY

for finishing off with two

protective installation.

mating Cover Plates leaving a durable and

- The DMP provides
- · A secure anchor for the faucet
- Clean and precise drywall installation
- Fire retardant plastic

The DMP Mounting Plate can be configured in a horizontal or vertical position ready for faucet installation and plumbing hook-up.

Made from strong PC/ABS, the 4" X 91/4" Mounting Plate is designed to space the faucet wall flange away from 5/8" drywall just enough




Parts ncludina Fasteners ln Kit










RK-OSF Over Sized Flange

FITS WOODFORD MODELS: 14, 16, 17, 19

- Fits behind an existing Woodford faucet flange to secure a loose fitting faucet or cover a larger opening in the wall.
- Requires 3/8" space behind original flange.



RK-ADJ-PRV ADJUSTABLE OPERATING ROD

FOR USE WITH MODELS 14, 16, 17, 19, 22, V22

- Adjustable Operating Rod assembles and adjusts for combinations of 4" to 14" model lengths in 2" increments.
- Includes the patented, resetting Pressure Relief Valve (PRV) upgrade. The PRV is designed to prevent the copper tube from bursting in freezing conditions even if a hose is unintentionally left on.
- Includes (4) all brass stems and (2) stainless steel clips plus (1) each replacement parts EPDM Packing, Packing Nut, Round Metal Handle and Handle Screw. Complete instructions are provided with each RK-ADJ-



NOTICE

- All faucets are intended For Irrigation and Outdoor Watering.
- · All faucets are not recommended for continuous use.
- · All specifications are subject to change without notice.

Visit our website for Patent Information, Individual Spec. Sheets, Installation and Troubleshooting Instructions www.woodfordmfg.com or call 1-800-621-6032

Installation Requirements:

- The inlet connection must be located in a heated area.
- · The gap between the house and faucet must be sealed to prevent air leaks.
- The faucet must be installed with a slight downward pitch toward the nozzle
- Adequate insulation is required around the faucet wall board and sill plate

Limited Warranty

All goods are sold with a limited warranty for one year against defects in material and workmanship. We will replace or issue credit (at our option) for defective goods that are returned for inspection and found to be defective within one year of purchase from Woodford.

Limited 5 Year Warranty Model 19

All **Model 19** Wall faucets are sold with a limited warranty for five (5) years against defects in material and workmanship. We will replace or issue credit (at our option) for defective goods that are returned for from Woodford. In addition, Woodford will pay up to \$5,000.00 toward the cost to repair damages incurred as a result of a defective Model 19 Wall Faucet that was properly installed. This limited warranty does not cover defects caused by: modification, alteration or repair of the product by anyone other than Woodford; physical abuse to, or misuse of, the product or operation thereof in a manner contrary to



inspection and found to be defective within five (5) years of purchase accompanying instructions.











Freezeless Residential Wall Faucets



Add-On Vacuum Breakers & Backflow Preventers

Ideal for hose connections to prevent backflow conditions. Brass and Stainless Steel components Standard Brass (BR) Optional: Chrome Plated (CH) 3/4" female hose thread inlet 3/4" male hose thread outlet nozzle 125 p.s.i. Max Pressure

120° F Max Temperature

NIDEL® Model 34H Vacuum Breaker

- For non-freezing areas only
- ASSE 1011 Approved, Listed by IAPMO Approved by Canadian Standards Association
- One (1) rubber diaphragm

NIDEL® Model 34HD Vacuum Breaker Same specs as 34H

- Includes a theft resistant stainless steel stop collar
- Manual draining is required
- Use in freezing and non-freezing conditions

Patented NIDEL[®] Model 50H **High Flow Double Check Backflow Preventer**


ASSE 1052 Approved Field Testable

- Two (2) independent rubber diaphragms
- · Drains automatically when hose is removed
- No sprav back
- Use in freezing and non-freezing conditions



Woodford Manufacturing Company, LLC. 2121 Waynoka Road Colorado Springs, CO 80915 USA 800-621-6032 800-765-4115 (Fax) sales@woodfordmfg.com www.woodfordmfg.com

© Woodford Mfg. Co. 2013 Printed in the U.S.A.



Woodford freezeless wall faucets are designed to provide year-round outdoor water service regardless of outside temperature.

All models are suited for residential and light commercial applications.

Four models include the patented, resetting, Anti-Burst Pressure Relief Valve (PRV). See page 2 for details

- · Wall thickness: 4" 24" in 2" increments
- 3/4" male hose thread nozzle
- Stainless steel seat eliminates wire draw
- EPDM Packing
- · Full circle operating threads on valve body and retainer
- · No lead solder on all solder joints
- Standard "O" size beveled seat washer
- Powder coated die cast aluminum wheel handles • Tee key option available
- Adjustable polycarbonate wall flange (N/A 22/V22)
- Adjustable packing nut
- Red brass head casting
- 5/16" solid brass valve stem
- Check valve on valve stem
- MAX PRESSURE; 125 p.s.i.
- MAX TEMPERATURE: 120° F

Scan For Specifications, Installation and Troubleshooting




For information, please contact:

Freezeless Residential Wall Faucets **Specifications / Inlets**



Freezeless Residential Wall Faucets Parts Lists / Rough-In Dimensions

When ordering, specify model, Inlet and Wall Thickness.......Example 19CP-12




SHIPPING WEIGHTS (Lbs. Each)

Model / Wall Thickness (inches) 4 6 8 10 12 14 16 18 20 22 24

1.2 1.3 1.4 1.5 1.6 1.7 1.8 1.9 2.0 2.1 2.2


2.8 3.0 3.2 3.4 3.6 3.8 4.0 4.2 4.4 4.6 4.8

4.5 4.8 5.2 5.5 5.9 6.2 6.6 6.9 7.3 7.6 8.0



30421 Stepped Washer Use with Model 17, 19, 22 & V22

		MODEL 16 & 19
ITEM	PART#	DESCRIPTION
1	30002	Handle Screw
2	30559	Oval Wheel Handle-Metal
3	30059	Packing Nut
4	30560	EPDM Packing
5	30421	Packing Support Washer (Stepped-19)
6	30006	Packing Support Washer (Flat-16)
7	RK-PRV	PRV Valve Stem Assembly (see chart-page 4)
8	30459	Check Valve
9	30008	Valve Seat Rubber
10	30804	Retainer Screw (with hole)
11	RK-19VB	Vacuum Breaker Float Kit (Model 19)
12	30098	Adjustable Flange
13	30512	Packing Nut w/deep stem guard (Optional)
14	50012	Tee Key (Optional)
	RK-19	Repair Kit (Includes items 1-5,8-11)



14, 16, 17, 19

22

32




11

WOODFORD Freezeless Residential Wall Faucets Parts Lists / Rough-In Dimensions



	ITEM	PART#	DESCRIPTION
	1	30002	Handle Screw
	2	30096	Round Wheel Handle-Metal
	3	30059	Packing Nut
	4	30560	EPDM Packing
	5	30421	Packing Support Washer (Stepped-17)
	6	30006	Packing Support Washer (Flat-14)
	7	357XX	14-17 Valve Stem Assembly (see chart-page 4)
1	8	30459	Check Valve
	9	30008	Valve Seat Rubber
	10	30009	Retainer Screw
	11	RK-17VB	Vacuum Breaker Float Kit (Model 17)
	12	30098	Adjustable Flange
	13	30512	Packing Nut w/deep stem guard (Optional)
	14	50012	Tee Key (Optional)
		RK-14MH	Repair Kit (Includes items 1,2,3,4,6,9,10)
		RK-17MH	Repair Kit (Includes items 1,2,3,4,5,8-11)

MODEL 14, & 17




MODEL 22 & V22			
ITEM	PART#	DESCRIPTION	
1	30002	Handle Screw	
2	30559	Oval Wheel Handle-Metal	
3	30059	Packing Nut	
4	30560	EPDM Packing	
5	30421	Packing Support Washer	
6	RK-PRV	PRV Valve Stem Assembly (see page 4)	
7	30459	Check Valve	
8	30008	Valve Seat Rubber	
9	30804	Retainer Screw	
10	30566	Plug Button-H-Red	
11	30565	Plug Button-C-Blue	
12	RK-22VB	Vacuum Breaker Float Kit	
13	30512	Packing Nut w/deep stem guard (Optional)	
14	50012	Tee Key (Optional)	
	RK-22PRV	' Repair Kit (metal handles) Includes	
		1 ea: Items 10, 11, 12	
		2 ea: Items 1 - 5, 7 - 9	


and any	ITEM
	1
	2
	3
	4
9	5
\sim	6
AS ASSEMBLY ONLY	7
1 2 3 4 ACACCEMBET ONET	8
	9
	10
OVERALL LENGTH	11
INLET	12
MUST BE 17/8" H WALL THICKNESS - 3" + 5" - 5" - 5"	13

MODEL 32 PARTS LIST			
ITEM	PART#	DESCRIPTION	
1	50010	Long Tee Key	
2	30107	Packing Nut-brass	
3	30247	EPDM Packing	
4	55176	Head Nut Assembly	
5	51014	Yoke Nut	
6	50027	Support Washer	
7	51013	Ball Valve Rubber	
8	50028	Round Brass Nut	
9	50595	Union Nut	
10	50597	1" NPT Outlet	
11	50596	3/4" NPT Outlet	
12	50611	AS-124 O-Ring	
13	50035	1/4" Pipe Plug	
	553XX	Model 32 Operating Rod Assemblies (See chart for Overall Length)	
	RK-32	Repair Kit (Includes items 2-8, 12 & 13)	

Model 32 Operating Rod Assemblies			
• • •	VEARALL LENG		
Wall Thickness (Inches)	Overall Length (Inches)	Part No.	
4	5 1/2"	55304	
6	7 1/2"	55306	
8	9 1/2"	55308	
10	11 1/2"	55310	
12	13 1/2"	55312	
14	15 1/2"	55314	
16	17 1/2"	55316	
18	19 1/2"	55318	
20	21 1/2"	55320	
22	23 1/2"	55322	
24	25 1/2"	55324	







Model 14-17 Valve Stem Assemblies				
Overall Length				
	0 "			
Wall	Overall	Non-PRV		
Thickness	Length	Models		
(Inches)	(Inches)	14 & 17		
4	5 7/8	35720		
6	7 7/8	35721		
8	9 7/8	35722		
10	11 7/8	35723		
12	13 7/8	35724		
14	15 7/8	35725		
16	17 7/8	35736		
18	19 7/8	35726		
20	21 7/8	35737		
22	23 7/8	35738		
24	25 7/8	35727		

	Model 16, 19, 22, V22 PRV Valve Stem Assemblies			
↓ 0	verall Leng	th		
Wall Thickness (Inches)	Overall Length (Inches)	Part No.		
4	5 7/8	RK-PRV-4		
6	7 7/8	RK-PRV-6		
8	9 7/8	RK-PRV-8		
10	11 7/8	RK-PRV-10		
12	13 7/8	RK-PRV-12		
14	15 7/8	RK-PRV-14		
16	17 7/8	RK-PRV-16		
18	19 7/8	RK-PRV-18		
20	21 7/8	RK-PRV-20		
22	23 7/8	RK-PRV-22		
24	25 7/8	RK-PRV-24		