Freezeless Yard Hydrants





The original Woodford Model Y34 has been manufactured continuously by Woodford since 1929. Time tested functionality and dependability make Woodford the most requested brand for freezeless yard hydrants.

Freezeless Yard Hydrants are intended for irrigation purposes and outdoor watering on the farm or ranch where immediate water flow is required in sub-zero temperatures. Yard Hydrants are typically used for filling field spray equipment, cleaning tools and equipment, lawn and garden care and watering livestock.

The shut-off valve is located below the frost line where water in the stand pipe is allowed to drain from the valve body to prevent freezing.

All repairs can be made from the top of the unit without removing hydrant from the ground.

8 Yard Hydrant models are featured in this brochure. Specifications for each are listed on page 2.

Scan For Specifications, Installation and Troubleshooting



For information, please contact:

Freezeless Yard Hydrants Model / Specifications



When ordering, specify model and bury depth......Example Y34-6

	Female Pipe	Galv. Steel	nodel and bury depthExample Y34-6
MODEL	Inlet	Pipe Casing	Specifications
IOWA® Y34 Orange Head	3/4" N.P.T.	1" (1-5/16" O.D.)	 Cast iron head and handle assembly Cast brass valve body 1/8" NPT drain hole 3/8" galvanized steel pipe Operating Rod w/brass stem Rod Guide eliminates side pull on rod Adjustable lever lock tension link Automatic Flow Finder and lock Long Life graphite Packing One piece variable flow Plunger and drain feature Available in Low Lead (LL)
IOWA [®] Y1 Orange Head	1" N.P.T.	1 1/4" (1-5/8" O.D.)	Same features as Y34Available in Low Lead (LL)
Y2 Orange Head	1" N.P.T.	1 1/4" (1-5/8" O.D.)	 Same features as Y34 *ASSE 1052® Nidel Model 50HF High Flow Double Check Backflow Preventer Automatic draining Diverter Vent Available in Low Lead (LL)
W34 Orange Head	3/4" N.P.T.	1" (1-5/16" O.D.)	 Metal side links 3/8" galvanized steel pipe Operating Rod w/brass stem Cast iron head and handle assembly Cast brass valve body with drain hole Long Life graphite Packing One piece variable flow Plunger and drain feature
X34 Blue Head	3/4" N.P.T.	1" (1-5/16" O.D.)	 Nylon plastic side links 3/8" steel operating rod w/brass stem Cast iron head and handle assembly Cast brass valve body with drain hole Long Life graphite Packing One piece variable flow Plunger and drain feature
R34 Red Head	3/4" N.P.T.	1" (1-5/16" O.D.)	 Ductile iron head and handle assembly All metal construction (No plastic parts) Cast brass valve body 1/8" NPT drain hole Long Life graphite Packing One piece variable flow Plunger and drain feature Adjustable pivot block provides easy and positive adjustment of the lever lock in tension 3/8" steel operating rod w/brass stem
Y30 Wheel Handle Operation Brass Head	3/4" N.P.T.	1" (1-5/16" O.D.)	 Large oval wheel handle operation (Optional Tee Key) EPDM Packing 3/8" galvanized steel pipe Operating Rod Cast brass faucet style head Cast brass valve body with drain hole
Y95 Flush With Ground Brass Box Model	3/4" N.P.T.	1" (1-5/16" O.D.)	 Concealed flush to surface installation *ASSE 1052 Nidel® Model 50HF High Flow Double Check Backflow Preventer EPDM Packing 3/8" galvanized steel pipe Operating Rod Tamper proof 6.5 X 7.5 X 3.4 deep cast brass box with hinged, locking flat brass cover Brass head casting with removable tee key operation
	Common to all	I Yard Hydrants	 Max Working Pressure: 125 P.S.I. Max Temperature: 120° F
S	HIPPING WEIGHT	(Lbs)	SHIPPING WEIGHT (Lbs)
Model / Bury Depth (Ft)	1 2 3	4 5 6	* 7* Model / Bury Depth (Ft) 1 2 3 4 5 6* 7*

SHIPPING WEIGHT (Lbs)							
Model / Bury Depth (Ft)	1	2	3	4	5	6*	7*
**Y34	15	17	19	22	24	26	28
**Y1	18	20	22	25	28	31	34
Y2	18	20	22	25	28	31	34

20

24

26


*6 & 7 ft. bury must ship by truck line due to length.
**Y34 & Y1 are also available in 8, 9 & 10 ft. lengths.


SH	SHIPPING WEIGHT (Lbs)						
Model / Bury Depth (Ft) 1 2 3 4 5 6* 7*							
X34 14 16 18 20 22 24 26					26		
R34	9.2	11.3	13.4	15.5	17.6	19.7	21.8
Y30 8 10 13 15 17 19 21							
Y95	14	16	18	21	23	26	28
*6 & 7 ft. bury must ship by truck line due to length.							

W34

Freezeless Yard Hydrants Rough-In & Parts Lists







ITEM	PART#	DESCRIPTION
25		Y34, Y1 & Y2 Operating Pipe
	10023	1' Bury (35 ½" Long)
	10024	2' Bury (47 1/2" Long)
	10025	3' Bury (59 1/2" Long)
	10026	4' Bury (71 ½" Long)
	10027	5' Bury (83 1/2" Long)
	10028	6' Bury (95 1/2" Long)
	10029	7' Bury (107 ½" Long)
	10030	8' Bury (119 1/2" Long)
	10089	9' Bury (131 1/2" Long)
	10090	10' Bury (143 ½" Long)
	RK-Y34	Repair Kit (Includes Items 3-6 & 18)
	RK-Y1	Repair Kit (Includes Items 3-6 & 20)
	RK-YHL	Repair Kit (Includes Items 8-14)

		Y34, Y1 & Y2 PARTS LIST	
ITEM	PART#	DESCRIPTION	
	15003	Y34 Head Assembly (Includes Items 1, 3-16)	
	15001	Y1 Head Assembly (Includes Items 2, 3-15 & 17)	
	15239	Y2 Head Assembly (Includes Items 3-15, 22, 23, 24)	
1	15004	Y34 Head with 3/4" Nozzle	
2	15002	Y1 Head with 3/4" Nozzle	
3	10100	Packing Nut	
4	10101	Packing	
5	10102	Packing Support Washer	
6	10104	Brass Rod Stem	
7	10011	Reducing Coupling	
8	10206	Hex Nut (3)	
9	10009	Upper Link	
10	15007	Lower Link (Includes Item 11)	
11	10019	Set Screw (2)	
12	15008	Cam & Clevis Assembly	
13	10020	Link Bolt (2)	
14	10021	Lever Bolt	
15	10008	Lever	
16	10004	3/4" Brass Hose Nozzle (Standard)	
17	10007	1" Brass Hose Nozzle (Optional)	
18	10105	Y34 Plunger	
19	10018	Y34 Valve Body (3/4" NPT Inlet)	
20	10106	Y1 & Y2 Plunger	
21	10017	Y1 & Y2 Valve Body (1" NPT Inlet)	
22	10539	Y2 Head	
23	50HF-BR	50HF-BR Dual Check Backflow Preventer ASSE 1052	
24	15238	Diverter Assembly	

Optional on Y34 & Y1 at additional cost:


- 1" Brass Pipe Outer Casing
 3/8" Brass Pipe Operating Rod
 1" Hose Nozzle (10007)

Optional on Y1 & Y2 at additional cost:

• Low Lead - Add suffix (LL) to model number

Freezeless Yard Hydrants Rough-In & Parts Lists









ITEM	PART#	DESCRIPTION
25		X34 Operating Rod (%" Steel Rod)
	10471	1' Bury (36 11/16" Long)
	10472	2' Bury (48 11/16" Long)
	10473	3' Bury (60 11/16" Long)
	10474	4' Bury (72 11/16" Long)
	10475	5' Bury (84 11/16" Long)
	10476	6' Bury (96 11/16" Long)
	10477	7' Bury (108 11/16" Long)
	RK-W34	Repair Kit (Includes Items 1-7)
	RK-X34	Repair Kit (Includes Items 1-4, 6, 7, 23)

TITEM PART# DESCRIPTION			W34 & X34 PARTS LIST	
15039	ITEM	PART#	DESCRIPTION	
15037 X34 Head Assembly - Complete (Includes Items 1-4, 6, 7, 12, 17-21) 1		15020	W34 Head Assembly - Complete	
10100		15059	(Includes Items 1-4, 6-16)	
1		15037		
2 10101 Packing 3 10102 Packing Support Washer 4 10104 Brass Rod Stem 5 10105 W34 Plunger 6 10158 Pivot Set Screw 7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ½" Brass Hose Nozzle (Optional) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 <td< td=""><td></td><td></td><td></td></td<>				
3 10102 Packing Support Washer 4 10104 Brass Rod Stem 5 10105 W34 Plunger 6 10158 Pivot Set Screw 7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Optional) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22	1	10100	Packing Nut	
4 10104 Brass Rod Stem 5 10105 W34 Plunger 6 10158 Pivot Set Screw 7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	2	10101	Packing	
5 10105 W34 Plunger 6 10158 Pivot Set Screw 7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Optional) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24		10102		
6 10158 Pivot Set Screw 7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	4	10104	Brass Rod Stem	
7 10159 Pivot 15050 Pivot Assembly (Includes Items 6 & 7) 8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Optional) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 <td< td=""><td>5</td><td>10105</td><td>W34 Plunger</td></td<>	5	10105	W34 Plunger	
15050 Pivot Assembly (Includes Items 6 & 7)	6	10158	Pivot Set Screw	
8 10144 Steel Link (2 Req'd) 9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long)	7	10159		
9 10157 Link Bolt 10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)		15050	Pivot Assembly (Includes Items 6 & 7)	
10 10146 Link Spacer 11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	8	10144	Steel Link (2 Req'd)	
11 10206 Link Bolt Nut 12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	9	10157	Link Bolt	
12 10142 Handle Pin 13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	10	10146	Link Spacer	
13 10211 W34 Handle (Orange) 14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1 Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	11	10206	Link Bolt Nut	
14 10011 W34 Reducing Coupling 15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	12	10142	Handle Pin	
15 15040 W34 Orange Head & Nozzle Assy (Includes Item 16) 16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	13	10211	W34 Handle (Orange)	
16 10004 ¾" Brass Hose Nozzle (Standard) 17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	14	10011		
17 10007 1' Brass Hose Nozzle (Optional) 18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (¾" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	15	15040	W34 Orange Head & Nozzle Assy (Includes Item 16)	
18 10018 Valve Body 19 15021 Head & Nozzle Assembly-Blue (Includes Item 16) 20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	16	10004	3/4" Brass Hose Nozzle (Standard)	
19	17	10007	1' Brass Hose Nozzle (Optional)	
20 RK-WXL Replace with Steel Links (Includes Items 8(2),9-11) 21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	18	10018	Valve Body	
21 10227 X34 Handle (Blue) 22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	19	15021	Head & Nozzle Assembly-Blue (Includes Item 16)	
22 10481 X34 Coupling Nut 23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	20	RK-WXL	Replace with Steel Links (Includes Items 8(2),9-11)	
23 10109 X34 Plunger 24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	21	10227	X34 Handle (Blue)	
24 W34 Operating Pipe (%" Galv. Steel Pipe) 10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	22	10481	X34 Coupling Nut	
10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	23	10109	X34 Plunger	
10023 1' Bury (35 ½" Long) 10024 2' Bury (47 ½" Long) 10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)	24		W34 Operating Pipe (%" Galv. Steel Pipe)	
10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)		10023	1' Bury (35 ½" Long)	
10025 3' Bury (59 ½" Long) 10026 4' Bury (71 ½" Long) 10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)		10024	2' Bury (47 ½" Long)	
10027 5' Bury (83 ½" Long) 10028 6' Bury (95 ½" Long)		10025		
10028 6' Bury (95 ½" Long)		10026	4' Bury (71 ½" Long)	
		10027	5' Bury (83 ½" Long)	
10029 7' Bury (107 ½" Long)		10028	6' Bury (95 ½" Long)	
		10029	7' Bury (107 ½" Long)	


Freezeless Yard Hydrants Rough-In & Parts Lists












	Y30 PARTS LIST				
ITEM	PART#	DESCRIPTION			
1 1a	30002 30121	Handle Screw (brass) Handle Screw (nickel)			
2 2a	10630 50022	Oval Wheel Handle (brass) Round, Clear Wheel Handle (chrome)			
3 3a	30107 30109	Packing Nut (brass) Packing Nut (chrome)			
4	30247	Packing			
5 5a	55178 55179	Head Nut Assembly (brass) Head Nut Assembly (chrome)			
6	10109	Yoke Nut			
7	10105	Plunger			
8 8a	50075 50076	Head (brass) Head (chrome)			
9	10018	Valve Body			
10	3/8" Ope	rating Pipe			
	10033	1' Bury (28-1/8" long)			
	10034	2' Bury (40-1/8" long)			
	10035	3' Bury (52-1/8" long)			
	10036	4' Bury (64-1/8" long)			
	10037	5' Bury (76-1/8" long)			
	10038	6' Bury (88-1/8" long)			
	10110	7' Bury (100-1/8" long)			
	RK-Y30	Brass Repair Kit (Items 1-7)			



Y95 PARTS LIST					
ITEM	PART#	DESCRIPTION			
1	50010	Tee Key			
2	30107	Packing Nut			
3	30247	EPDM Packing			
4	55176	Head Nut Assembly			
5	10109	Yoke Nut			
6	10105	Plunger			
7	10018	Valve Body			
8	50HF-BR	50HF Vacuum Breaker- Brass			
9	55020	Box Assembly			
10		3/8" Operating Pipe			
	10031	1' Bury (4-1/8" long)			
	10032	2' Bury (16-1/8" long)			
	10033	3' Bury (28-1/8" long)			
	10034	4' Bury (40-1/8" long)			
	10035	5' Bury (52-1/8" long)			
	10036	6' Bury (64-1/8" long)			
	10037	7' Bury (76-1/8" long)			
	RK-Y95	Repair Kit (Items 1-6)			

Freezeless Yard Hydrants Information



Notice

- All Yard Hydrants must be buried so that the valve body is located below the frost line for proper draining.
- · All hydrants are intended For Irrigation and Outdoor Watering.
- · All hydrants are not recommended for continuous use.
- · All specifications are subject to change without notice.

Visit our website for Patent Information, Individual Spec. Sheets, Installation and Troubleshooting Instructions www.woodfordmfg.com or call 1-800-621-6032

Limited Warranty

All hydrants shown in this brochure are sold with a limited warranty for one year against defects in material and workmanship. We will replace or issue credit (at our option) for defective goods that are returned for inspection and found to be defective within one year of purchase from Woodford.

*NIDEL® Model 50HF Backflow Preventer



The patented NIDEL® Model 50HF high flow double check backflow preventer is standard equipment on specified Yard Hydrant models. It is intended for irrigation and outdoor watering and is designed to protect hose connections from backflow contamination in freezing and non-freezing conditions.

The Model 50HF automatically drains when the hose is removed and unlike single check vacuum breakers can be field tested for reliability.

- ASSE 1052 Approved
- Field Testable (see instruction sheet)
- Two independent check valves
- · Drains automatically when hose is removed
- No spray back

Sanitary & Heated Yard Hydrants See separate brochure for models and features. S4H Thermaline® H34



Woodford Manufacturing Company, LLC. 2121 Waynoka Road Colorado Springs, CO 80915 USA 800-621-6032 800-765-4115 (Fax) sales@woodfordmfg.com www.woodfordmfg.com

© Woodford Mfg. Co. 2013 Printed in the U.S.A.